CONTROL PANEL PARTS

For Models: KHHS179LWH5, KHHS179LBT5, KHHS179LBL5, KHHS179LSS5
(White) (Biscuit) (Black) (Stainless Steel)

MICROWAVE HOOD COMBINATION

KitchenAid®



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8205975	Use & Care Guide
	8205622	Tech Sheet
	8205574	Tech Sheet, Insert
	8205139	Installation Instructions
	8184803	Cook Book
	8184723	Cook Guide Label
2		Button Assembly
	8205434	White
	8205437	Black
	8205436	Biscuit
	8205092	Stainless
3		Control Panel
	8185164	White
	8185167	Black
	8185166	Biscuit
	8185165	Stainless
4	8185174	Bracket, Control
5	8185172	Touch Pad
6	8205423	Microcomputer
7	8184913	Ring, Rubber
9	8204689	LCD Assembly
10	8184915	Bracket, LCD
11	8185058	Bushing, Rubber
12	8184919	Sensor, Light Lens

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: KHHS179LWH5, KHHS179LBT5, KHHS179LBL5, KHHS179LSS5
(White) (Biscuit) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
3	8184113	Latch, Door
6	8184922	Pivot, Door
7		Handle
	8205431	White
	8205433	Black
	8205432	Biscuit
	8185156	Stainless
8	8185157	Nameplate
9	8169479	Screw
11	8205438	Screw
13	8204679	Hinge, Upper
14	8204678	Hinge, Lower
15		Complete Door
	8185160	White
	8185163	Black
	8185162	Biscuit
	8185161	Stainless Steel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERIOR AND VENTILATION PARTS

For Models: KHHS179LWH5, KHHS179LBT5, KHHS179LBL5, KHHS179LSS5
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERIOR AND VENTILATION PARTS

For Models: KHHS179LWH5, KHHS179LBT5, KHHS179LBL5, KHHS179LSS5
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Reflector, Lamp
	8184194	Left
	8184132	Right
2	8204670	Lamp
3	4393598	Switch, Micro
4	8184003	Filter, Grease
5	8205381	Plate, Bottom
	8204960	(SS Model)
6	8184141	Glass, Lamp
7	8184889	Holder, Glass
8	4393599	Switch, Micro Primary/Secondary
9	8184124	Cover, Inverter
10	4393697	Switch, Micro
11	8169438	Spring, Interlock
12	8205211	Plate, Cam
13	8185189	Support, Interlock
14	8184875	Fan, DC 12 Volt
15	8184894	Housing, Fan
16	8204989	Inverter 40 W
17	8185032	Bracket, Holder
18	8184670	Holder, Inverter
19	8185190	Rod−Locking Link
20	8184093	Capacitor, 125 V
21	8205093	Inverter 1100 W
22	8185031	Plate, Side
23	8184887	Cable
24	8184002	Filter, Charcoal
25	8184579	Fuse (2) 4 Amp/250 Volt
26	8184204	Capacitor, Motor
27	8184312	Holder, Fuse
28	4393308	Fuse
29	8183998	Thermostat
30	8184199	Screw
31	4393835	Screw
32	8184200	Screw
33	8185177	Fuse Holder (2)
34	8169477	Screw
35	8205021	Ribbon Cable (P27 To CN153 On 40 W Inverter)
36	8205022	Ribbon Cable (P4 To CN151 On 40 W Inverter)
37	8205014	Ribbon Cable (P2 To CN701 On 1100 W Inverter)
38	8184603	Wire Assembly

AIR FLOW PARTS

For Models: KHHS179LWH5, KHHS179LBT5, KHHS179LBL5, KHHS179LSS5
(White) (Biscuit) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	8184667	Deflector, Air
2	8184885	Cover, Lamp
3	8205402	Duct, Air
4	8205401	Bracket, Thermostat
5	8183999	Thermostat
6	8204676	Air Guide Cover
7	8185188	Lamp
8	8184884	Cover, Fan
9	8184876	Motor, Fan Assy
10	8204754	Shield
11	8169647	Spring
12	8204790	Shield
13	4393834	Screw
14	8184198	Screw
15	8169474	Screw
17	4393808	Humidity, Sensor
18	8205853	Filter
19	8204669	Holder, Lamp
21	8184129	Spacer−Copper Pipe
22	8204674	Plate, Damper
23	8169635	Cushion, Mtr

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MAGNETRON AND TURNTABLE PARTS

For Models: KHHS179LWH5, KHHS179LBT5, KHHS179LBL5, KHHS179LSS5
(White) (Biscuit) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4393746	Motor, Stirrer
2	8205202	Stirrer Shaft/Blade
3	8184485	Shield, Nomex
4	8184585	Thermostat/Bracket
5	8185059	Cover, Inlet Includes Nails and Bushings
6	4393849	Hook, Rack (4)
7	8184549	Nails/Bushings (5 of each)
8	4393799	Turntable
9	8205778	Ring, Turntable
10	8184109	Spacer, Waterproof
11	8205779	Driver, Turntable
12	8183953	Motor, Turntable
13	4393756	Cover, Terminal
14	8184139	Magnetron
15	8184951	Thermostat
16	8205042	Rack
17	8184862	Grill
18	4393838	Screw
19	8204652	Handle, Crisper Plate
20	8204670	Halogen Light
21	4393832	Screw
22	8204669	Socket, Halogen Light
23	8184586	Thermostat/Bracket
24	8184669	Bracket, Plug
25	8204995	Thermostat
26	8205409	Grill, Insulation Plate
27	8184837	Browner, Halogen
28	8184838	Quartz Tube, Soft Start
29	8169499	Glass, Lamp
30	8169646	Frame, Glass
31	8184839	Heater, Quartz
32	8205239	Cover, Protector
33	8204983	Plate, Crisp
34	8185175	Insulation, Front
35	8185176	Insulation, Rear
36	8205039	Spacer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND INSTALLATION PARTS

For Models: KHHS179LWH5, KHHS179LBT5, KHHS179LBL5, KHHS179LSS5
(White) (Biscuit) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	8206173	Plate, Mounting
3	4393713	Door, Damper
4	8184897	Lid, Power Cord
5	8205772	Damper Assembly
6	8184898	Cord, Power
7		Case, Outer
	8205397	White
	8205398	Black
	8205399	Biscuit

Illus. No.	Part No.	DESCRIPTION
8		Grille, Vent
	8205427	White
	8205430	Black
	8205429	Biscuit
	8205428	Stainless
9	8184190	Clip, Grille
10	4393836	Screw
11	8169475	Screw
12	4393472	Screw
18	8184902	Plate, Damper

Illus. No.	Part No.	DESCRIPTION
Miscellaneous		
	8205947	Installation, Hardware
	8184781	Template, Upper
	8169704	Screw, Top Mountng
	8184603	Wire Harness (Includes light sockets)
	8206231	Harness from Magnetron to CN703

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST